

19.11.2019

UNCERTAINTY FROM SAMPLING OF TRACE EXPLOSIVES AMOUNTS AND DETECTION BY ION MOBILITY SPECTROMETRY

Carlo Tiebe, Mehmet E. Bayat,
Matthias Bartholmai

Acknowledgements



Sigrid Benemann, Astrid Walter, Jörg Schlischka, Lothar Buchta
for technical support

Grant number: 50.0369-2017

Luftfahrt-Bundesamt (LBA)

German Federal Ministry of Transport and Digital Infrastructure (BMVI)

This presentation is based on work that was carried out on behalf of the German Federal Ministry of Transport and Digital Infrastructure under FE-No. 50.0369-2017. The responsibility for the content lies exclusively with the authors.

1. Introduction

- Security checks and air cargo

2. Method

- Ion mobility spectrometry as ETD-method
- Logistic regression

3. Results

- Comparison of POD0.9 in dependence of deposition and sampling
- Measurement uncertainty for Boolean results

4. Conclusions and Summary

Introduction

- Loading of approximately 2.3 Mt airfreight at German airports in 2019

January to June 2019,
https://www.destatis.de/DE/Presse/Pressemitteilungen/2019/08/PD19_320_464.html


- 50% of the total airfreight is transported in civil aviation planes
- Protection against threats on air traffic security
- Regulatory responses in D / EU → increased freight controls, restructuring “secure supply chain”



MergeGlobal Inc.: Global Air Freight: Demand Outlook and its Implications, Lizenziertes Dokument, 2019, S. 10.
Bundeszentrale für politische Bildung (2009). Interview with the author. Retrieved on <https://www.dailymail.co.uk/news/article-2905276/Al-Qaeda-publishes-recipe-easy-make-bomb-evade-airport-check-determined-Muslim-prepare.html>, 2019-11-17.

Cargo and mail shall be screened by at least one of the following methods


- hand search
 - x-ray equipment
 - Explosive detection systems (EDS)
 - Explosive detection dogs (EDD)
 - Explosive trace detection (ETD)
 - visual check
 - metal detection equipment (MDE)
- Waybill content must match the x-ray picture



K. Osterloh, N. Wrobel, U. Ewert

Section 6.2.1.1. - EU Reg. 2015/1998

Process approach | staged detection process



x-ray of palletised airfreight ($E \leq 300$ keV)

Content: ???


Picture provided by C. Weißkopf, Smith Heimann, 2016.




Method

www.bam.de


- Substances or mixtures of substances which, after energetic activation, react within a few seconds, releasing a high amount of energy
- Tests referring to **ASTM E2520 - 15**, Standard Practice for Measuring and Scoring Performance of Trace Explosive Chemical Detectors




TNT



HMX



RDX



PETN

ECAC certified devices



Bruker Daltonik
DE-tector



Safran
Itemiser 4DX



Smiths Detection
Ionscan 600



L3 Security & Det. Sys.
QS-B220





Nuctech | TR2000DB



1st Detect
Tracer 1000
Linear Ion Trap Mass Spectrometer


European Civil Aviation Conference (ECAC), <https://www.ecac-ceac.org/>, Certified ETD devices <https://www.ecac-ceac.org/documents/10189/62763/ECAC-CEP-ETD-Web-Update-20-February-2019.pdf/771e9026-a606-4a30-b8cf-6316e165b2d1>, all pictures from the producers' homepage or data sheets.

General set-up



Figures: D-TeC System Consulting GmbH, Systeminformation QS-B220 (in German), **2014**, http://www.d-tec-system.de/m/pdf_dl_QS-B220%20mit%20Drucker.pdf

Ion mobility spectrometry (IMS)



$$K_0 = K \cdot \left(\frac{T_0}{T}\right) \cdot \left(\frac{p}{p_0}\right)$$

$$= \frac{s}{t_d \cdot E} \cdot \left(\frac{T_0}{T}\right) \cdot \left(\frac{p}{p_0}\right)$$

K_0 = reduced mobility in $\text{cm}^2/(\text{V}\cdot\text{s})$

K = mobility in $\text{cm}^2/(\text{V}\cdot\text{s})$

T_0 = 273.15 K

T = drift tube temperature in K

p = gas pressure in hPa

p_0 = 1013.25 hPa



s = drift tube length in cm

t_d = drift time in s



E = electric field in V/cm

More information about IMS: G. A. Eiceman, Z. Karpas, H. H. Hill, *Ion Mobility Spectrometry*, 3rd edition, CRC Press Taylor & Francis Group, Boca Raton, <https://doi.org/10.1201/b16109>, **2015**.

Application on surfaces – two methods




Swab sampling




Example: Blank

Blank sample trap → no alarm → true negative (TN)




Example: Swab sample

Swab sample from a laboratory table surface → alarm → false positive (FP)



Example: Swab sample of a suspicious surface

- Alarm indication when a detected amount of substance exceeded a threshold → true positive (TP)





Results

www.bam.de

Boolean screening results

- Yes/No-indications $Y_i \in \{1,0\}$
- True-positive rate (sensitivity, probability of detection (POD))



ETD device		Explosive		
		Presence (1)	Absence (0)	Total
	Alarm (A)	TP	FP	TP+FP
	No Alarm (A*)	FN	TN	FN+TN
	Total	TP + FN	FP + TN	N




Performance characterisation for binary classification via performance function


- POD = Positive test results (TP) over applied explosive mass

$$POD = \frac{L}{1 + e^{-A(m-B)}}$$

$L = 1$
 $A =$ logistic growth rate
 $B =$ mass value of $POD_{0.5}$
 $m =$ independent variable



Logit function of a real example



Description	Process equations
Weighed portion	$m_E = m_{nom} \cdot PUR$
Stock solution	$\beta_s = \frac{m_E}{V}$
Dilution	$\beta_i = \frac{V_{s-eq} \cdot \beta_s}{V_i}$
Mass deposit	$m_{dep} = \beta_i \cdot V_{Pip}$

Preparation of a calibration standard, GUM Workbench example "example A1.smu",
S. L. R. Ellison, A. Williams (eds.), Quantifying Uncertainty in Analytical Measurement
EURACHEM / CITAC Guide 2012.

Weighed portion: Resolution of balance

- 0.00001 g
- Calibration certificate 0.00011 g
- Repeatability 0.0001 g
- Purity: substance depending

Stock solution – acetone/methanol (10/90 and 500 mL):

- Flask label (class B) 0.3 mL
- Temperature 0.1 mL/K
- Repeatability 0.001 L

Test solution (100 mL)

- Flask label (class A): ± 0.1 mL
- Temperature: 0.1 mL/K
- Repeatability ± 0.2 mL
- Pipetted volume of stock ± 2 %

Deposition:

- Pipetted volume of the test solution

Further unquantified causes:
Dust and solvent effects

Budget for mass deposit

Description	X_i	x_i	$u(x_i)$	$c_i(y_j)$	$u_i(y_j)$	$h_i(y_j)$
Weighed portion	m_E	0.4995 g	1.040E-03 g			
Weighed portion on balance display	m_{nom}	0.5 g				
Resolution of balance	δA	0 g	5.770E-06 g	40	2.300E-04 ng	0.0 %
Calibration certificate	δCAL	0 g	6.350E-05 g	40	2.500E-03 ng	0.0 %
Repeatability	δR	0 g	1.000E-03 g	40	4.000E-02 ng	4.9 %
Purity	PUR	0.999	5.770E-04	20	1.200E-02 ng	0.4 %
Mass concentration stock solution	b_s	0.999 g/L	4.380E-03 g/L			
Nominal stock solution volume	$V_{s-nominal}$	0.5 L				
Calibrated Volume (flask label)	$f_{V-s-calibration}$	1	1.730E-03	-20	-3.500E-02 ng	3.7 %
Temperature influence	$f_{V-s-temperature}$	1	3.290E-03	-20	-6.600E-02 ng	13.4 %
Repeatability	$f_{V-s-repeatability}$	1	1.000E-03	-20	-2.000E-02 ng	1.2 %
Mass concentration of test solution	b_i	0.01998 g/L	8.890E-05 g/L			
Aliquote volume of stock solution	V_{s-eq}	0.002 L				
Nominal test solution volume	$V_{i-nominal}$	0.1 L				
Calibrated Volume (flask label)	$f_{V-i-calibration}$	1	5.770E-04	-20	-1.200E-02 ng	0.4 %
Temperature influence	$f_{V-i-temperature}$	1	4.850E-04	-20	-9.700E-03 ng	0.3 %
Repeatability	$f_{V-i-repeatability}$	1	2.000E-04	-20	-4.000E-03 ng	0.0 %
Conversion factor 1E+3	$k_{Volumen}$	1000 ng·L/(g· μ L)				
Pipetted volume	V_{pip}	1 μ L				
Repeatability	δImp	1	7.690E-03	20	1.500E-01 ng	73.0 %
Systematic error (data sheet)	δSE	1	1.440E-03	20	2.900E-02 ng	2.6 %
	Y_j	y_j	$u(y_j)$			
Mass of the explosive (k = 1)	m_{dep}	19.98 ng	0.9 %			

$$POD = \frac{L}{1 + e^{-A(m-B)}}$$

Inverse POD-function

$$m_{0.9} = \frac{A \cdot B - \ln\left(\frac{L}{POD} - 1\right)}{A} = \frac{A \cdot B - \ln\left(\frac{1}{0.9} - 1\right)}{A}$$

Sensitivity coefficients of parameters A and B

Budget equation


$$m_{0.9} = \frac{A \cdot B - \ln\left(\frac{1}{0.9} - 1\right)}{A} \cdot \delta m_{\text{dep}}$$

$$\frac{dm_{0.9}}{dA} = \frac{\ln\left(\frac{1}{0.9} - 1\right)}{A^2}$$

$$\frac{dm_{0.9}}{dB} = 1$$

Measurement uncertainty of $POD = 0.9$

Direct deposit and swab sampling from a surface



Direct

$$m_{0.9} = 12.3 \text{ ng}$$

Swab sampling

$$m_{0.9} = 711.4 \text{ ng}$$

Coefficient

$$C = \frac{m_{0.9\text{-swab}}}{m_{0.9\text{-direct}}} = 57.8$$

Measurement uncertainty of POD

Direct deposit and swab sampling from a surface

Direct	Description	X_i	x_i	$u(x_i)$	$c_i(y_j)$	$u_i(y_j)$	
	POD with 0.9 TP-rate	POD _{0,9}	0.9				
	Parameter A	A	0.244 ng ⁻¹	0.064 ng ⁻¹	-36.770	-2.361 ng	
	Parameter B	B	3.339 ng	0.904 ng	1	0.904 ng	
	Limited POD	L	1	0	-40.908	0.000	
	Mass deposit	δm_{dep}	1	0.90 %	12.327	0.111 ng	
		Y_j	y_j	$u(y_j)$			
Mass of the explosive (k = 1)	m_{dep}	12.3	ng	2.5 ng	20.5 %		
Mass of the explosive (k = 2)				5.1 ng	41.1 %		

Swab sampling, solvent transfer	Description	X_i	x_i	$u(x_i)$	$c_i(y_j)$	$u_i(y_j)$	
	POD with 0.9 TP-rate	POD _{0,9}	0.9				
	Parameter A	A	0.009 ng ⁻¹	0.003 ng ⁻¹	-28244.720	-83.322 ng	
	Parameter B	B	462.235 ng	27.219 ng	1	27.219 ng	
	Limited POD	L	1	0	-1133.787	0.000	
	Mass deposit	δm_{dep}	1	0.90 %	711.353	6.402 ng	
		Y_j	y_j	$u(y_j)$			
Mass of the explosive (k = 1)	m_{dep}	711.4	ng	87.9 ng	12.4 %		
Mass of the explosive (k = 2)				175.8 ng	24.7 %		

- IMS is a useful method for explosive trace detection as well as narcotics detection and supports primary screening results of suspicious objects / potential threats within the staged detection process before an air plane takes off
- Method to determine measurement uncertainty for ETD on the basis of Boolean results
- $POD_{0.9}$: direct deposit < swab sampling
- Expression of measurement uncertainty on binary results (up to 48 h after deposition at ambient conditions)
- Not all alarms mark a threat (*FP*-results, plausibility check of the air waybill content and x-ray pictures)