Measurement uncertainty in the case of large and heterogeneous variances

Eurachem Workshop – Uncertainty from sampling and analysis for accredited laboratories 19.-20. November 2019, Berlin


Steffen Uhlig Kirsten Simon Bertrand Colson Karina Hettwer Kirstin Frost



In-house study at four concentration levels




In-house study with 4 spike levels (5, 10, 15 and 20 µg/kg) and 20 replicates



In-house study at four concentration levels



Prediction interval: in which interval does a future measurement fall with a certain probability under a given statistical model and a precision study already carried out? The calculation depends on the statistical model, here the log normal distribution with decreasing standard deviation.




Uhlig et al, Asymmetric Measurement Uncertainty, Eurachem 2019, Berlin

www.quodata.de

A graphical method for the evaluation of the uncertainty interval



The uncertainty interval can graphically be derived from the prediction interval.




Uncertainty interval belonging to 10 µg/kg: 4.5 µg/kg to 16 µg/kg

A graphical method for the evaluation of the uncertainty interval



Other results will be obtained if the evaluation of the prediction interval is conducted under the assumption of a log normal distribution, here with constant standard deviation ($\sigma = 0.35$)



Uncertainty interval belonging to 10 μ g/kg: 5 μ g/kg to 20.1 μ g/kg (uncertainty factor = 2,01)


Uhlig et al, Asymmetric Measurement Uncertainty, Eurachem 2019, Berlin

www.quodata.de

A graphical method for the evaluation of the uncertainty interval



The evaluation of the uncertainty interval can also be performed with normal distribution and constant standard deviation = 4.3. Then the uncertainty interval corresponds to the conventional measurement uncertainty.



Uncertainty interval belonging to 10 μ g/kg: 1.4 μ g/kg to 18.6 μ g/kg (10 \pm 2 \cdot 4.3)

Comparison of results



	Uncertainty interval (k=2) for 10 µg/kg
(1) graphical solution based on log-normal with decreasing RSD	4,5 – 16
(2) uncertainty factor FU=exp(2s _G)=2.01	5 – 20.1
(3) conventional measurement uncertainty U(10)=8.6	1.4 - 18.6

Upper limits are similar, whereas the lower limit of the conventional measurement uncertainty (3) is clearly smaller than the lower limits of (1) and (2).


Uhlig et al, Asymmetric Measurement Uncertainty, Eurachem 2019, Berlin

www.quodata.de

A graphical method for the evaluation of the uncertainty interval: another example



In case of larger RSD, the uncertainty interval becomes highly asymmetric. Here the prediction band is calculated under the assumption of a normal distribution with constant RSD = 0.43.



Uncertainty interval belonging to 5 μg/kg: 2.7 μg/kg to 35.7 μg/kg.

Calculation formula for the case of a normal distribution with constant RSD



Under the assumption of normal distribution with constant RSD there is also a formula for the uncertainty interval:

A given measurement result y obtained at the known concentration level x will lie with 95 % probability in the interval $[x - 1.96 \cdot x \cdot RSD, x + 1.96 \cdot x \cdot RSD]$.

This is equivalent with

$$x \cdot (1 - 1.96 \cdot RSD) \le y \le x \cdot (1 + 1.96 \cdot RSD)$$

$$\frac{1 - \mathbf{1.96} \cdot RSD}{y} \le \frac{1}{x} \le \frac{1 + \mathbf{1.96} \cdot RSD}{y}$$

$$\frac{y}{1 + \mathbf{1.96} \cdot RSD} \le x \le \frac{y}{1 - \mathbf{1.96} \cdot RSD}$$

With RSD=0.43, k=2 and y=5:

$$\frac{5}{1+2\cdot 0.43} \le x \le \frac{5}{1-2\cdot 0.43},$$

$$2.7 < x < 35.7 \mu g/kg$$

Uhlig et al, Asymmetric Measurement Uncertainty, Eurachem 2019, Berlin

www.quodata.de

Discussion



- A simple method of calculating the uncertainty interval is the graphical method described in the presentation (based on a prediction band). It can be used for both normal and log normal distribution
- Under the normal distribution with constant standard deviation, the graphical method is equivalent with the conventional measurement uncertainty.
- According to the graphical method, uncertainty intervals are not only depending on the distribution of the data but also on the dependency of the RSD on the concentration level.
- A clear distinction between log normal distribution and normal distribution requires a large number of data points that are not always available.

Discussion



• A worst case solution is as follows: use lower limit from conventional measurement uncertainty, and upper limit from the normal distribution model with constant RSD:

lower limit =
$$x - 2 \cdot x \cdot RSD$$

upper limit =
$$\frac{x}{1-2 \cdot x \cdot RSD}$$

(x = measured value)

- If RSD>0.5, the upper limit from the normal distribution model with constant RSD becomes infinite. In other words, RSD = 0.5 is an ultimate limit under the assumption of the normal distribution.
- Procedures for the calculation of the prediction interval are described in ISO DTS 23471 (draft to be published in 2020).

Uhlig et al, Asymmetric Measurement Uncertainty, Eurachem 2019, Berlin

www.quodata.de



Many thanks for your attention!



QuoData GmbH 10787 Berlin, Ansbacher Straße 11 01309 Dresden, Prellerstraße 14 E-Mail: uhlig@quodata.de